


PARTS

- (A) POSTS (2)
- (B) LEGS (4)
- (C) LARGE END CAPS (4)
- (D) ARMS (4)
- (E) SQUARE CROSS BRACES (2)
- (F) ROUND CROSS BRACES (2)
- (G) MACHINE SCREWS (4)
- (H) WOOD PLUGS (4)
- (I) SMALL END CAPS (4)
- (J) HANGER BOLTS (4)

HARDWARE ILLUSTRATION

Tools required: Screwdriver (not included)



ATTENTION: SOME NUMBERED PARTS LISTED ON THE INSTRUCTION SHEET MAY NOT BE IN PARTS BAG AS THEY MAY ALREADY BE ASSEMBLED. CAREFULLY CHECK PARTS AND PACKING MATERIALS PRIOR TO ORDERING REPLACEMENTS.

Thank you for purchasing this Powell product. We want to make sure it is complete and to your satisfaction. Please check all packing material carefully for small parts which may have come loose inside the carton during shipment. Hardware can be identified by bright red packaging. Separate, identify, and count all parts and hardware to make sure they match with the illustrations herein and are all present. If any part(s) are missing or defective please contact Powell Customer Service. Contact information is given at the bottom of these instructions. If you feel the item is defective beyond a resolution with part replacements, please return this product with your receipt to the place of purchase. If purchased from an internet retailer, please contact their customer service department. Photo's and additional information may be requested to validate the claim. Product is not to be returned to the Powell Company under any circumstance unless authorized by the Powell Company or an authorized dealer or representative. Thank you.

IMPORTANT NOTE: Follow instructions listed below in the proper sequence as numbered to assure fast, easy and correct assembly.

1. **Note:** Upon opening, thoroughly clean all wood surfaces with furniture polish to remove dust and dirt that may have settled onto finish during shipment.
2. Slide Legs (B) into grooves on one end of Posts (A). Tighten Large End Caps (C) into bottom edge of Legs (B) to secure Legs (B) to Posts (A).
3. Slide Arms (D) into grooves on opposite end of Posts (A). Tighten Large End Caps (C) into top edge of Arms (D) to secure Arms (D) in place. Be sure that large holes on Arms (D) are facing inward toward each other.
4. Align Square Cross Braces (E) with slots in Posts (A). Insert Hanger Bolts (J) into large holes near ends of Square Cross Braces (E) with threads pointing outward. If necessary, rotate Hanger Bolts (J) so that threads will align with Machine Screws (G). Insert Machine Screws (G) through Posts (A), Legs (B), and tighten into Hanger Bolts (J).
5. Align Round Cross Braces (F) with large holes on ends of Arms (D). Insert threads of Small End Caps (I) through small hole in Arms (D) and tighten into ends of Round Cross Braces (F). Be sure that large holes on Arms (D) are facing toward each other.
6. Insert Wood Plugs (H) into screw holes on Posts (A).
7. Your furniture has been handcrafted and skillfully finished by fine craftsmen. Rich, deep antique finishes have been applied which require very little polish. However, should you desire a shinier finish, simply use any good grade of furniture polish, rubbing the finish lightly as it is being applied. Allow to dry and buff lightly with a soft cloth.

