ASSEMBLY INSTRUCTION FOR ACME FURNITURE

MODEL#92227 / #92228 / #92229

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the cation during shipment. Seperate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.


*** Do not fully tighten screws until fully assembled ***

COMPONENT PARTS								
DESCRIPTION	PART NAME	QTY (PCS)	DESCRIPTION	PART NAME	QTY (PCS)			
1	TOP PANEL	1	9	LEFT DRAWER SIDE	2			
2	BOTTOM PANEL	1	10	RIGHT DRAWER SIDE	2			
3	BACK PANEL	1	11)	DRAWER BACK	2			
4	LEFT PANEL	1	12	DRAWER BOTTOM	2			
5	RIGHT PANEL	1	13	CROSS TUBE	2			
6	CENTER PANEL	1	14)	LEG FRAME	8			
7	LEFT DRAWER FACE	1	15)	II -FRAME	2			
8	RIGHT DRAWER FACE	1						

HARDWARE REQUIRED

							
A		ALLEN KEY		1 PC			
\bigcirc		CAM BOLT	34.8mm	12 PCS			
©	THE RESERVE TO THE PARTY OF THE	CAM LOCK		12 PCS			
D		WOODEN DOWEL	Ø8mm*30mm	28 PCS			
Ē		SCREW	8#*38mm	16 PCS			
F	(a))))))))))))))))))))	BOLT	φ1/4"*38mm	6 PCS			
(G)		BOLT	φ1/4"*19mm	32 PCS			
\bigoplus		BOLT	φ5/32"*12mm	4 PCS			
<u>(I)</u>		BOLT	8#*32mm	4 PCS			
\bigcirc		WASHER		16 PCS			
(K)		PLUG	20mm*40mm	8 PCS			
		KNOB		2 PCS			
\bigcirc	glue	GLUE		1 PC			


Attention






*** Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and packing materials prior to ordering replacements.

How to assemble:



STEP 2



STEP 3 **13** STEP 4 **G** 14 STEP 5

