

ASSEMBLY INSTUCTIONS FOR MODEL #A353V8-K

MUST SCREW IN LEGS