

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

215791KE(B1-B3)
Eastern King Bed

ITEM: 215791KE(B1-B3)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

25 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A HEADBOARD
PANEL



1PC

B LEFT HEADBOARD
LEG (WITH "L" LABEL)




1PC

C RIGHT HEADBOARD
LEG (WITH "R" LABEL)



1PC


D ADAPTER



1PC

B2 (BOX 2)

E FOOTBOARD



1PC

F BED SLAT



4PCS

G BED SLAT SUPPORT
WITH LEVELER



8PCS

H FOOTBOARD LEG



2PCS

B3 (BOX 3)


I BED RAIL



2PCS

HB


215791KE(B1)
FROM BOX 1
HEADBOARD
COMPLETE



1PC

FB

215791KE(B2)
FROM BOX 2
FOOTBOARD
COMPLETE



1PC

ITEM: 215791KE(B1-B3)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 215791KE(B1)

- | | | | | | | | |
|---|--|--|------|---|---|--|-------|
| 1 | SMALL ALLEN WRENCH
(M4 x 65mm - BLK) |  | 1PC | 3 | LOCK WASHER
(1/4" - BLK) |  | 6 PCS |
| 2 | BOLT
(M6 x 30mm - BLK) |  | 6PCS | 4 | FLAT WASHER
(1/4" x 13mm - BLK) |  | 6 PCS |

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 215791KE(B2)

- | | | | | | | | |
|---|--|---|------|---|---|---|------|
| 5 | BIG ALLEN WRENCH
(M5 x 65mm - BLK) |  | 1PC | 8 | FLAT WASHER
(5/16" x 22mm - RBW) |  | 4PCS |
| 6 | BOLT
(M8 x 16mm - RBW) |  | 4PCS | 9 | FLAT HEAD SCREW
(M4 x 32mm - RBW) |  | 8PCS |
| 7 | LOCK WASHER
(5/16" - RBW) |  | 4PCS | | | | |


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.


ITEM: 215791KE(B1-B3)

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: 215791KE(B1-B3)

ASSEMBLY INSTRUCTIONS




STEP 3



**** BOTTOM VIEW**

STEP 4




ITEM: 215791KE(B1-B3)

ASSEMBLY INSTRUCTIONS


STEP 5



5.3




Loosen the screw to connect




On & off touch switch button

5.1



G



leveler


5.2



9

F


STEP 6 COMPLETE



ITEM: **215791KE(B1-B3)**



Inner size: 76.50"W x 80.50"D



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

215792
Nightstand

ITEM: **215792**

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B LEG



4PCS


HARDWARE IDENTIFICATION

1 ALLEN WRENCH
(M5 x 65mm - BLK)



1PC

2 BOLT
(M8 x 16mm - RBW)



8PCS

3 LOCK WASHER
(5/16" - RBW)



8PCS

4 FLAT WASHER
(5/16" x 22mm - RBW)



8PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **215792**

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




***BOTTOM VIEW**



ITEM: **215792**

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4 **COMPLETE**



ITEM: **215792**



Inner Size of Drawer : 17.00"W X 13.25"D X 7.50"H X 0.25"T



Note: Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

215793
Dresser

ITEM: **215793**

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A DRESSER



1PC

B LEG



4PCS

C CENTER SUPPORT LEG
WITH LEVELER



1PC


HARDWARE IDENTIFICATION

1 ALLEN WRENCH
(M5 x 65mm - BLK)



1PC

2 BOLT
(M8 x 16mm - RBW)



8PCS

3 LOCK WASHER
(5/16" - RBW)



8PCS

4 FLAT WASHER
(5/16" x 22mm - RBW)



8PCS

5 FLAT HEAD SCREW
(M4 x 32mm RBW)



4PCS

6 WOOD DOWEL
(Ø6 x 30mm)





2PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **215793**
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2




ITEM: **215793**

ASSEMBLY INSTRUCTIONS


STEP 3





3.1



3.2



STEP 4 COMPLETE



ANTI-TIPPING INSTALLATION INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.



This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.


1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
4. Attach the bracket over the plastic wall anchor using the long screw.
5. Place the unit against the wall, both brackets need to be facing each other.
6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
7. Ensure that the restraint strap is securely laced and locked.



ITEM: **215793**




Inner Size of Drawer : 27.25"W X 12.75"D X 5.25"H X 0.25"T



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

215794
Mirror

ITEM: **215794**

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A	MIRROR		1PC
B	MIRROR SUPPORT (PACKED WITH MIRROR)		2PCS
C	ADAPTER		1PC
D	DRESSER (FROM BOX ITEM 215793)		1PC


HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 65mm - BLK)		1PC
2	BOLT (M6 x 35mm - BLK)		8PCS
3	LOCK WASHER (1/4" - BLK)		8PCS
4	FLAT WASHER (1/4" x 19mm - BLK)		8PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **215794**
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2





***BACK VIEW**


ITEM: **215794**
ASSEMBLY INSTRUCTIONS
STEP 3



STEP 4
COMPLETE



ITEM: **215794**



Note : Dimension tolerance $\pm 5\%$