

40215 W14" H30" L1

## Lamp Assembly Instructions

Please read all instructions carefully. Before you proceed to install, make sure that the power supply is turned off and off until installation is complete. Please note that each part has been assigned a letter. Please proceed in alphabetical order.

### ASSEMBLY INSTRUCTIONS:

1. Place the Lamp body Assembly on a level surface.
2. Insert the harp until it sits firmly in the saddle.
3. Adjust the knurl nut on the harp. This can be used to raise the shade if necessary.
4. Place the shade onto the top of the harp and tighten with the finial securing the shade in place.

FOR RETURN SHIPPING PURPOSES: PLEASE RETAIN ORIGINAL PACKAGING TO MINIMIZE DAMAGE

Uses 40 WATT "E26" Bulb  
(Bulb not supplied)



### Important Safety Instructions

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted.



Listed


**\*SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE\*.**

Made in China

01

40215 W14" H30" L1

## Lamp Assembly Instructions



02

Shade Size	
Top	Ø12"
Bottom	Ø14"
Height	11"