


ASSEMBLY INSTRUCTIONS

MODEL #

YNJ-2280C31

Questions?

GIVE US A CALL: 1-888-980-5122
MON – FRI 8:30AM – 5:30PM (PST)



TOOLS REQUIRED



**Phillips
Screwdriver**

(Not Included)



Hammer

(Not Included)



**2 - People
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT


The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.




Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.

 **Consumer Hotline**
Toll-Free 1-888-980-5122

 **Monday to Friday**
8:30AM- 5:30PM (PST)

 **WEBSITE**
www.foagroup.com

 **E-MAIL**
cs.ec@foagroup.com



CHECK BEFORE STARTING

Are you missing anything?
Double-check all parts, hardware and accessories listed are all accounted for.


Check out our Quick Tips!
We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

Should we send any replacements?
Are there any irregularities or flaws in the parts? We can send replacements!

Prep Time!
Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS

Note :

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.



cam bolt



cam lock



screwdriver



1

Screw the cam bolt into panel.



2

Insert the cam bolt into the bolt hole of joint panel.



3

Align the cam lock with its side opening (or arrow) pointing to cam bolt.




4


Turn the cam lock clockwise gently until it will not turn any more.

TV STAND

YNJ-2280C31




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS


A 1PC




E 1PC




I 1PC




M 1PC




B 1PC




F 1PC




J 2PCS




N 1PC




C 1PC




G 1PC




K 2PCS




O 1PC




D 1PC



H 1PC



L 1PC



HARDWARE

① 32PCS ② 36PCS ③ 2PCS ④ 21PCS



⑤ 10PCS ⑥ 2PCS ⑦ 4PCS ⑧ 4PCS



ACCESSORIES


A1 6PCS A2 1PC A3 12PCS A4 1PC




GET READY

Please group boards as below.


E 1PC




F 1PC




G 1PC




H 1PC




B 1PC




C 1PC




D 1PC




I 1PC




L 1PC




M 1PC




N 1PC




A 1PC




J 2PCS



K 2PCS



O 1PC



Body


ASSEMBLY INSTRUCTIONS

1

Hardware ① x18PCS

Hardware ④ x2PCS

Accessory A4 x1PC



OPTIONAL


Apply a dab of glue into dowel holes of panels before inserting dowels (#4).

ASSEMBLY INSTRUCTIONS

2

Hardware ① x4PCS
Hardware ④ x9PCS

Accessory A4 x1PC









ASSEMBLY INSTRUCTIONS

3

Hardware ① x10PCS

Hardware ④ x10PCS

Accessory A4 x1PC





ASSEMBLY INSTRUCTIONS

4

Part **G** x1PC
Part **H** x1PC

Hardware **5** x2PCS



Accessory **A2** x1PC



5

Part **E** x1PC
Part **F** x1PC

Hardware **2** x4PCS




ASSEMBLY INSTRUCTIONS

6

- Part **B** x1PC
- Part **C** x1PC
- Part **D** x1PC
- Part **I** x1PC

Hardware **(5)** x8PCS

Accessory **(A2)** x1PC




RECOMMEND
Recommend using a power tool to only tighten hardware (#5) faster. Accessory (#A2) could also work for hardware (#5) if a power tool is not present.

ASSEMBLY INSTRUCTIONS

7

Part **L** x1PC
Part **M** x1PC
Part **N** x1PC


Hardware **②** x4PCS
Hardware **③** x2PCS



8

Hardware **②** x6PCS

Accessory **A3** x2PCS




ASSEMBLY INSTRUCTIONS

9

Part **J** x2PCS

Part **K** x2PCS


Hardware **②** x4PCS



10

Hardware **②** x6PCS

Accessory **A1** x6PCS




ASSEMBLY INSTRUCTIONS

11

Part **A** x1PC
Part **O** x1PC

Hardware **2** x12PCS



Accessory **A3** x10PCS



ASSEMBLY INSTRUCTIONS

12

Hardware ⑥ x2PCS
Hardware ⑦ x4PCS
Hardware ⑧ x4PCS



13

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

