

E-Commerce

ASSEMBLY

**INSTRUCTIONS** 

### MODEL # HFW-2271C42


#### **Questions?**

GIVE US A CALL: 1-888-980-5122 MON – FRI 8:30AM – 5:30PM (PST)

### **TOOLS REQUIRED**




#### Philips Screwdriver (Not Included)







2 - People Recommended



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

#### VERSION # 22-05-11






#### Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



# PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















#### Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.

#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.

#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.


#### Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

### ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

### **CAM LOCK FASTENER** ASSEMBLY **INSTRUCTIONS**


#### Note :

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.











Screw the cam bolt into panel.




Align the cam lock with its side opening (or arrow) pointing to cam bolt.

cam bolt

cam lock



Insert the cam bolt into the bolt hole of joint panel.




Turn the cam lock clockwise gently until it will not turn any more.





 Please keep instructions for future reference.


 Check the quantity and irregularity of parts and hardware before you start.



PARTS











2


Hardware 1x16pcsHardware 3x12pcs (8x30)Hardware 4x2pcs (8x50)




















Part  $\bigcirc$  x 1 pc Part  $\bigcirc$  x 1 pc Hardware  $\bigcirc$  x 2 pcs




## 5


Part  $\bigcirc$  x 1 pc Hardware  $\bigcirc$  x 10 pcs







**10** Part (a) x 1 pc Hardware (2) x 10 pcs Accessories (A2) x 1 pc



## 11

### ASSEMBLY COMPLETED



furniture rests on an eve and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

### $\oslash$

 $\oslash$ 

#### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

### Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

