



Assembly Instructions


3714101 Gensler Bar Cart

**Product Issues? Please Call Us Before Contacting Your Retailer At
1-800-549-3300, email customerservice@mshome.com, or visit mshome.co
We can help with Assembly Issues, Part Requests, Damages, & All Other
Product Related Questions**






10 min




Two People Required



Approximate
space required

12ft

13ft



Do not use power tools




ALLEN KEY

Replacement Parts:


A - Wooden tray x 2

B - Legs x 2




Hardware Pack:

C






8 X 16MM = 12 PCS

D




ALLENKEY - 5MM = 1 PCS

1



2



4-5

