



Instruction Manual







www.festival-usa.com

US Customer Service Hotline : +1 840-244-5399

Us CustomerService E-mail:customerservice.festivalneo@gmail.com



This is not solid wood!



Daily Maintenance Instructions



Dust Removal

Please wipe with a damp cloth.



Daily Cleaning

Please clean with neutral detergent.



Scratches Avoided

Please carry the product carefully to avoid contact with sharp or hard objects, which may cause damages or scratches.



Scratch Repair


Please use the touch up paint (if have) to repair slight scratches.

Daily Maintenance Instructions



Hazardous Substance Avoided

Please avoid contact with strong acid or alkali, if spilled accidentally, please rinse with water immediately.



Safety Reminder

Please pay attention to the weight capacity and avoid children jumping on the product.



Warm Reminder

It is recommended to store the product when not in use (over one month), protecting the possible damage from harsh weather. Proper protection can prolong its life span.