



# Instruction Manual







[www.festival-usa.com](http://www.festival-usa.com)

US Customer Service Hotline : +1 840-244-5399


Us CustomerService E-mail:[customerservice.festivalneo@gmail.com](mailto:customerservice.festivalneo@gmail.com)



**This is not solid wood!**



# Daily Maintenance Instructions



## Dust Removal

Please wipe with a damp cloth.



## Daily Cleaning

Please clean with neutral detergent.



## Scratches Avoided

Please carry the product carefully to avoid contact with sharp or hard objects, which may cause damages or scratches.



## Scratch Repair


Please use the touch up paint (if have) to repair slight scratches.

# Daily Maintenance Instructions



## Hazardous Substance Avoided

Please avoid contact with strong acid or alkali, if spilled accidentally, please rinse with water immediately.



## Safety Reminder

Please pay attention to the weight capacity and avoid children jumping on the product.



## Warm Reminder

It is recommended to store the product when not in use (over one month), protecting the possible damage from harsh weather. Proper protection can prolong its life span.