



*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

551913

OTTOMAN

ITEM: 551913

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES


PARTS IDENTIFICATION

	PART NAME	FIGURE	QUANTITY
A	OTTOMAN		1PC
B	LEG		4PCS


ITEM: 551913

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2




STEP 3



STEP 4



ITEM: 551913



Note : Dimension tolerance $\pm 5\%$

