

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

503066
CHAIR

ITEM: 503066



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

8 MINUTES


PARTS IDENTIFICATION

A. CHAIR BASE



1PC

C. PILLOW



1PC

B. LEG




4PCS


ITEM: 503066
ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2



ITEM: 503066
ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$

