



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

503721  
**SOFA**

REVISION 0 : 01/20/2026

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 503721



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING !


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 10 MINUTES

## PARTS IDENTIFICATION

A. SOFA  
BASE




1PC

C. MIDDLE LEG




1PC

B. LEG



4PCS

D. PILLOW




2PCS


ITEM: 503721  
ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2



ITEM: 503721  
ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance  $\pm 5\%$

