

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

736069
Sofa Table

ITEM: **736069**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

A	TOP		1PC
B	LEG		4PCS
C	SHELF		1PC
D	CENTER SUPPORT LEG WITH LEVELER		1PC


HARDWARE IDENTIFICATION

1	LONG BOLT (1/4" x 50mm - BLK)		8PCS
2	SHORT BOLT (1/4" x 20mm - BLK)		4PCS
3	LOCK WASHER (1/4" x 14mm - BLK)		12PCS
4	FLAT WASHER (1/4" x 19mm - BLK)		12PCS
5	ALLEN WRENCH (4mm x 64mm - BLK)		1PC


ITEM: **736069**
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2




ITEM: **736069**
ASSEMBLY INSTRUCTIONS
STEP 3




STEP 4




ITEM: **736069**
ASSEMBLY INSTRUCTIONS
STEP 5



STEP 6




STEP 7
COMPLETE



ITEM: 736069



Inner Size of Drawer: 22.00"W x 11.25"D x 2.25"H x 0.50"T



Note: Dimension tolerance $\pm 5\%$