


PRE-ASSEMBLY TIPS

We get it - building furniture isn't always easy! But have no fear, helpful hints are here. Our assembly tips and tricks will have you enjoying that new furniture in no time. Let's get construction ready to rock!



TEAM ASSEMBLY

Have at least 2 people put the product together to prevent injury and damage.



ASSEMBLE IN PLACE

Put together near the intended location to avoid moving later.



CLEAR WORKSPACE

Ensure ample room to maneuver during assembly.




AVOID SCRATCHES

Assemble on cardboard, blankets, or carpet to prevent scratches.



FLAT SURFACE

Place on a level surface with furniture legs evenly contacting the floor.




ASSEMBLY SAFETY STEPS



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.


1



POSITIONING

Insert all hardware and parts in the correct holes.


2



TIGHTENING

Only tighten bolts when the step is fully completed.


3



TOOLS

Use hand tools unless the manual specifies power tools.


4



INSTRUCTIONS

Keep the manual and tools for future maintenance needs.

5



MAINTENANCE

Check for loose joints after 2 weeks and re-tighten every 6 months.

DISCLAIMER:

It is the user's responsibility to properly maintain the furniture over its lifetime. Hardware such as screws, bolts, and other fasteners may naturally loosen over time with normal use of the product. This can lead to instability if the furniture is unable to adequately support the intended weight capacity. To prevent injuries, following the maintenance instructions is key to ensuring product safety and longevity.

Model : F9637T/F9638T
/F9639T

Assembly Instruction

| | | | |
|---|--|---------------------------------------|-------|
| A | | Headboard | 1pc |
| B | | Footboard | 1pc |
| C | | Side Rail | 4pcs |
| D | | Headboard Legs 600 x 70 x 20mm | 2pcs |
| E | | Footboard Legs No.99 - 60 x 150(H) | 2pcs |
| F | | Side Rail Legs 240 x 80 x 30mm | 2pcs |
| G | | 12 pcs slat 997mm | 2pcs |
| H | | CSK Screw 32mm | 24pcs |
| I | | JCBB M8 x 20 | 8pcs |
| J | | JCBC M6 x 30 | 14pcs |
| K | | Allen Key 65mm | 1pc |
| L | | Allen Key 70mm | 1pc |
| M | | Spring Washers | 6pcs |
| N | | Flat Washers | 8pcs |

Step 1 : Take out all the parts from the back of headboard. Please be noted that this is an adjustable bed.

BACK VIEW

Step 2 : Fix the headboard (A) and footboard (B) with legs (D,E) as shown.


BACK VIEW

Step 3 : Attach the JCBB Bolt (I) to the headboard (A) and footboard (B).

FRONT VIEW

Step 4 : Attach the side rail leg (F) to the side rail (C).

Step 5 : Attach side rail (C) to headboard (A) and footboard (B) by pushing the bracket down to fit it.



Step 6 : Tighten the 4 Corner with Allen Key (L). Install the bed slats to side rail. Tighten the slats with CSK screw. The distance of the slats should be sufficient to obtain desirable bed stability.

