

## ASSEMBLY INSTRUCTIONS

Before assembling your headboard and footboard, please read through these instructions carefully and familiarize yourself with the different parts.

**ATTENTION!** If you receive a damaged or defective item, please contact afifurnishings at [customerservice@afifurnishings.com](mailto:customerservice@afifurnishings.com) or 1-800-955-3726








### PARTS LIST

- |   |                        |       |
|---|------------------------|-------|
| 1 | HEADBOARD PANEL BOARDS | 4 PCS |
| 2 | LEFT LEG               | 1 PC  |
| 3 | RIGHT LEG              | 1 PC  |
| 4 | HEADBOARD SUPPORT      | 1 PC  |
| 5 | FOOTBOARD PANEL BOARDS | 3 PCS |
| 6 | LEFT FOOTBOARD LEG     | 1 PC  |
| 7 | RIGHT FOOTBOARD LEG    | 1 PC  |
| 8 | FOOTBOARD SUPPORT      | 1 PC  |

Instructions apply for bed sizes  
**FULL > QUEEN**


### HARDWARE

- |   |   |   |
|---|---|---|
|  |  | <b>C</b> Wood screw ( 1 1/4" ) - 7 pcs<br>Spare - 1pc |
| <b>A</b> JCB M6 X 35mm - 28 pcs<br>Spare - 1 pc                                   |  | <b>D</b> Allen wrench M4 - 1pc<br>Spare - 1pc         |
|  |  | <b>E</b> Allen wrench M6 - 1pc                        |
| <b>B</b> JCB M8 X 15mm ( 5/8" ) - 8 pcs   |   |   |

NOTE: WE INCLUDE SPARE HARDWARE IN CASE DAMAGE OCCURS DURING ASSEMBLY.



### Step 1

Attach left leg (2) and right leg (3) to headboard panel boards (1) using JCB M6 X 35mm (A). Tighten with the Allen wrench M4 (D).




### Step 2

Attach headboard support (4) to headboard panel boards using wood screw 1 1/4" (C). Tighten with the Phillips head screw driver. (Customer supplied)




### Step 3

Attach left footboard leg (6) and right footboard leg (7) to footboard panel boards (5) using JCB M6 X 35mm (A). Tighten with the Allen wrench M4 (D).



### Step 4

Attach footboard support (8) to footboard panel boards using wood screw 1 1/4" (C). Tighten with the Phillips head screwdriver. (Customer supplied)



PO:

CODE	ITEM	ITEM
HBFB-ISL-OXD	G-12833X	G-12834X

FULL > QUEEN



- 01 HARDWARE
- 02 HEADBOARD
- 03 FOOTBOARD




BOX 1

- 01 HARDWARE
- 04 SIDE RAILS
- 05 SLAT KIT

BOX 2


## Step 1

Attach the side rails (04) to the headboard (02) and footboard (03) using JCB M8 X 15mm (B). Tighten with Allen wrench M6 (E).



## Step 2

Attach slat kit (05) onto the bed using wood screws. Tighten with Phillips head screw driver. (customer supplied) For assembly of slat kit, follow the assembly instructions included with slat kit.



## Congratulations!

Your bed is now ready for use.

We recommend that you periodically recheck that all screws are tight to ensure lasting safety.

## QUEEN

### ASSEMBLY INSTRUCTIONS

Before assembling your bed frame, please read through these instructions carefully and familiarize yourself with the different parts.

**ATTENTION!** If you receive a damaged or defective item, please contact [afifurnishings at customerservice.afifurnishings.com](mailto:afifurnishings@customerservice.afifurnishings.com) or 1-800-955-3726



#### PARTS LIST


- |   |                         |               |
|---|-------------------------|---------------|
| 1 | <b>SIDE RAIL</b>        | <b>2 PCS</b>  |
| 2 | <b>SLAT KIT</b>         | <b>2 SETS</b> |
| 3 | <b>SLAT SUPPORT</b>     | <b>2 PCS</b>  |
| 4 | <b>SLAT SUPPORT LEG</b> | <b>4 PCS</b>  |

- | HARDWARE |                              |
|----------|------------------------------|
| <b>A</b> | Wood screw (1 1/4") - 12 pcs |
| <b>B</b> | JCB M6 X 30mm - 6 pcs        |
| <b>C</b> | Cap nut - 6 pcs              |
| <b>D</b> | JCB M8 X 40mm - 4 pcs        |
| <b>E</b> | Split washer - 4 pcs         |
| <b>F</b> | Flat washer - 4 pcs          |
|          | Spare - 1 pc                 |

NOTE: WE INCLUDE SPARE HARDWARE IN CASE DAMAGE OCCURS DURING ASSEMBLY.


#### Step 1

Attach side rails (1) to the headboard and footboard. For assembly, follow the assembly instructions included with your headboard and footboard.




#### Step 2

Attach slat support legs (4) to slat support (3) as shown below using JCB M8 X 40mm (D) split and flat washer (E)(F) tighten with Allen wrench M6.





#### Step 3

Attach slat support (3) to the slat kit (2) as shown below using JCB M6 X 30mm (B) and cap nut (C). Tighten with Allen wrench M4.



#### Step 4

Attach the slat kit (2) onto the bed using wood screws 1 1/4" (A). Tighten with Phillips head screw driver. (customer supplied)



CODE	ITEM
FR-MT-ISL	G-24804X

**PO:**