

Lab Protocol			
Number	LP-G02-01.06.00		
Description	ASTM F2057-23 Standard safety for Clothing Unit Test		
	(Pure Protocols)		
Reference	ASTM F2057 - 2023		

	Customer Data			
Customer				
Contact				
Email				
Retailer/Brand	BUTLER SPECIALTY			

Report Author	Thorig
Test Technician	Bayu, Dicky, Ari
Lab	Surabaya
Date In	October 18, 2023
TAF Number	TA-E2310-0878
Report Date	November 1, 2023
Report Number	TR-E23-01443

RESULT				
PASS X FAIL				
INFO		COND		

	Vendor Data					
Name		Contact				
Email		Tel:				

		Product Data	
Item Description	6 Drawer Chest		
SKU Number	5766188	Affiliated SK	KU's /
PO Number	/	Country of C	Origin INDONESIA

Reason for Testing			Environmental Co	onditions	
Sampling Stage	Sampling Stage			Temperature (C°/F°)	33/91
Test History			RH (%)	47	



Test Result Summary

The item is rated as **PASS** after test.

This Report is issued within the provisions and conditions of the Terms and Conditions of Service of Outlook Technical Services PTE Ltd. (OTS) and is intended for the exclusive use of our Client. OTS retains all copyrights and reserves all rights to this document, and as such, this report may only be reproduced or copied with the written consent of OTS. This report describes and delineates the test results as determined by OTS and as described herein. Our findings are based solely on the Client samples submitted to OTS. As such, the results obtained thereof are neither necessarily indicative nor representative of the quality, characteristics, or function of the general lot of goods from which they were selected and provided to OTS by our Client. The tests requested by our Client, and the results thereof, are based upon the information and samples provided by our Client. Any issues or matters of disagreement, concern, or other objections as to our findings must be reported in writing to OTS no later than thirty days from the Date of Issue of this report. Failure to declare such issues and matters within this time period will serve as unqualified acceptance of this report, the tests as conducted, and their validity thereof.

TF-G02-01.06.00E Page 1 of 7 TR-E23-01443



Physical Characteristics				
Weight (KG/LB)	133 lbs	Material Type	·	

Dimensional Overview				
Primary Dimensions		Storage Spaces Dime	ension	
Whole Product (LxWxH)	62" x 20" x 31 ^{6/16} "	Number of Door	/	
Top Surface (LxW)	62" x 20"	Other Storage Area (DxWxH)	/	
Leg Height	4 ^{8/16"}	Other Storage Area (DxWxH)	/	
Leg Thickness	1 12/16"	Number of Shelves (Fixed)	/	
		Number of Shelves (Movable)	/	
		Fixed Shelve Dimensions	/	
		Fixed Shelve Dimensions	/	
		Movable Shelves Dimensions	/	
		Movable Shelves Dimensions	/	

	Determine	the load weigh in the drawers	s (Extendible Flem	ent)	
Extendible element height (HE) less than the smallest measurem	•	•	point on
the next obstruction above the	extendible elem	ent at any point of the travel follo	wing the opening ins	structions in 8.1.3.	•
Drawer Design 1 Top L		Drawer Design 2 Middle and		Drawer Design	n 3
Drawer bottom depth (in)	15 4/16"	Drawer bottom depth (in)	15 4/16"	Drawer bottom depth (in)	/
Drawer bottom width (in)	27 2/16"	Drawer bottom width (in)	27 2/16"	Drawer bottom width (in)	/
Drawer Height (in)	5 ^{10/16"}	Drawer Height (in)	5 ^{6/16} "	Drawer Height (in)	/
Drawer functional volume (ft3)	1.32	Drawer functional volume (ft3)	1.26	Drawer functional volume (ft3)	/
Test weight (lb)	11.2	Test weight (lb)	10.7	Test weight (lb)	/
Drawer Design 4 (centre	middle and	Drawer Design	n 5	Drawer Design	n 6
bottom 2 pcs)					
Drawer bottom depth (in)	/	Drawer bottom depth (in)	/	Drawer bottom depth (in)	/
Drawer bottom width (in)	/	Drawer bottom width (in)	/	Drawer bottom width (in)	/
Drawer Height (in)	/	Drawer Height (in)	/	Drawer Height (in)	/
Drawer functional volume (ft3)	/	Drawer functional volume (ft3)	/	Drawer functional volume (ft3)	/
Test weight (lb)	/	Test weight (lb)	/	Test weight (lb)	/

Volume Calculation Notes

- 1. Any volume with a height (H) less than 3 in. (76 mm) shall be excluded from all volume calculations.
- 2. Any continuous volume less than 0.06 ft3 (1.7 dm3) shall be excluded from all volume calculations unless the volume is created by a removable feature, for example, a removable jewellery tray, removable shelf, or other obstruction. In the case of a removable feature, remove such feature and re-evaluate.

Labeling Compliance					
Evaluation	Citation/Method	Criteria	Result		
Control to the order of the ord	Permanency of Labels and Warnings Testing LP-S02-07.43.00	ASTM F2057- 9.3 – 2023 1. A paper label shall be considered permanent if, during an attempt to remove it without the aid of tools or solvents, it cannot be removed, it tears into pieces upon removal, or such action damages the surface to which it is attached. 2. A non-paper label shall be considered permanent if, during an attempt to remove it without the aid of tools or solvents, it cannot be removed, or such action damages the surface to which it is attached.	М		





- 3. Adhesion Test for Warnings Applied Directly onto the Surface of the Product:
- 3.1 Apply the tape test defined in Test Method B Cross-Cut Tape Test of Test Methods D3359 eliminating parallel cuts.
- 3.2 Perform this test once in each different location where warnings are applied.
- 3.3 The warning statements shall be considered permanent if the printing in the area tested is still legible and attached after being subjected to this test.

ASTM F2057- 10 - 23

Each clothing storage unit shall be permanently marked in at least one place with the warnings from this section. The warnings shall be in a conspicuous location when in use; the back of the unit intended to be placed against the wall is not considered conspicuous when in use.



Black/White Version

Μ

▲ WARNING



Figure 1. Example warning for Clothing Storage units that are Not designed and intended by the manufacturer to be used with TV





Warning Label

Tip Over Warning Label LP-S02-07.13.00

TF-G02-01.06.00E Page 3 of 7 TR-E23-01443



A WARNIN



Children have died from furniture tipover To reduce the risk of furniture tipover: ALWAYS install Anti-tip device provided. Replace with statement addressing TV use. NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
-NEVER open more than one drawer at a time. Place heaviest items in the lowest draw

This is a permanent label. Do not remove!

Black/White Version

▲ WARNING

▲ WARNING



Children have died from furniture tipover To reduce the risk of furniture tipover: ALWAYS install Anti-tip device provided. Replace with statement addressing TV use. NEVER allow children to stand, climb or hang

on any drawers, doors, or shelves. -NEVER open more than one drawer at a time. Place heaviest items in the lowest drawers. This is a permanent label. Do not remove!

Figure 2. Example warning For Clothing Storage units that are designed and intended by the manufacturer to be used with a TV.

WARNIN



Children have died from furniture tipover. To reduce the risk of furniture tipover: -ALWAYS install Anti-tip device provided. -NEVER put a TV on this product.

NEVER allow children to stand, climb or



hang on drawers, doors, or shelves. -NEVER open more than one drawer at a time. -DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system. -Place heaviest items in the lowest

drawers.
This is a permanent label. Do not remove!

Figure 3. Example warning for unit with Interlocks Not Designed and Intended by the Manufacturer to be Used with a TV.

▲ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover: -ALWAYS Install Anti-tip device provided. -NEVER put a TV on this product. NEVER allow children to stand, climb or hang on drawers, doors, or shelves. -NEVER open more than one drawer at a

ume. -DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system. -Place heaviest items in the lowest

wers. This is a permanent label. Do not remove!

DO NOT remove the interlock system except for maintenance as shown. NEVER use the unit without the interlock installed following the instructions.

system Specific Instructions for System Specific Instructions for nterlock installation. System Specific Instructions for interlock installation

Figure 4. Example Warning Billboarded for Use with Interlocks Requiring in Unit Warnings

NM (Not Meet) N/A (Not Applicable) N/R (Not Requested) N/C (Not Checked) Legend M (Meet)

	Physical Tests	
Test Procedure	Criteria/Method	Results
	ASTM F2057 – 9.1 – 23	
Evaluate Interlock System LP-S02-01.76.00	 Open any doors prohibiting access to the interlocked extendible element. Open an extendible element or the number of elements necessary to engage the interlock. Gradually apply, over a period of at least 5 s, a 30-lbf (133 N) horizontal pull force on each interlocked extendible element at the center of the pull area(s), one element at a time, and hold the force for at least 10 s. 	N/A



UICAL 9	TEST IVEL 61	
	(Picture item tested) (Picture angled view)	
	Failure Details	
Stability Test LP-S02-01.77.00	1. Simulated Clothing Load: 1.1 Position the empty unit on test surface described in 8.2.1. For units with levellers, adjust the unit per 8.1.2. 1.2 If 50 % or more of the storage volume is extended, determine the weight for loading the extendable elements and/or space behind the doors based on the volume calculated in Vol (fts) = (W (in.) × D (in.) × H (in.) /1728) x 8.5lb. Load per 8.3.3. If less than 50 % of the storage volume is extended, the unit shall remain empty. 1.3 Open all doors and extend all available extendible elements in accordance with 8.1.3. Elements shall remain open for 30 s.	M
	2 Simulated Horizontal Dynamic Force: 2.1 Force Application on Extendible Element—Where the extendible element has been determined to have the highest hand-hold height, not to exceed 56 in. (1422 mm). • Apply a 10 lbf (44 N) horizontal force, parallel to the direction of outward motion, at the highest handhold, not to exceed 56 in. (1422 mm) on the extendible element most likely to cause tip over. The force shall be applied within 1/4 in. (6 mm) of the top edge of a drawer or to the centre of the pull area of the extendible element, whichever is higher but less than 56 in. (1422 mm) over a period of at least 5 s and held for 10 s. Result: 10.4 lbf	M



2.2 Force Application on Door with Handle/pull—

Where the door handle/pull has been determined to be the highest reach point not to exceed 56 in. (1422 mm).

Apply a 10 lbf (44 N) horizontal force, parallel to the direction of initial outward motion, at a height not exceeding 56 in. (1422 mm) to the handle or pull. The force shall be applied over a period of at least 5 s and held for 10 s. The door shall be in a position most likely to cause the unit to tip over. If the door handle or pull exceeds the max reach height, follow 2.1(3).

N/A

(Picture item being loaded)

(Angled View)

Failure Details

- 3 Simulating a Reaction on Carpet with Child Weight:
- 3.1 Position the empty unit on test surface described in 8.2.1. For units with levellers, adjust the unit per 8.1.2.
- 3.2 Place the test block(s) under the unit's most rear floor support(s), such as a leg, foot, or upright.
 3.3 Test block(s) shall be positioned so the back edge of the test block(s) are flush with the back edge of the rear floor supports. If the rear floor support is a glide tack, leveller, or foot smaller than 1 in., center the block under it.
- 3.4 Open all doors and extend all available extendible elements in accordance with 8.1.3.
- 3.5 Gradually, over a period of at least 5 s, apply the test apparatus without impact over the top of the door or extendible element most likely to cause tip over. Allow the test apparatus to rest without additional support for 30 s. If it is not apparent which door, extendible element, or for clothing storage units with interlock(s), the combination of open and closed extendible elements is most likely to cause tip over, perform multiple tests.
- 3.6 If the extendible element most likely to cause tip over is not the uppermost extendible element, any extendible element obstructing the test weight from being positioned properly shall be closed and reopened to the extent possible. For odd-shaped drawer, apply the test apparatus to the front edge that protrudes the farthest. For doors, apply the test apparatus to each door, one at a time, so that the outer edge of the test weight is flush with the outermost upper corner of the door.

Acceptance Level:

During the test, the unit shall not tip over or be supported by any component unless that component was specifically designed for that purpose.





Μ







LAB CONTACT INFORMATION



Contact Email