


ITEM NO.02347
CURIO CABINET
ASSEMBLY INSTRUCTIONS














ASSEMBLY INSTRUCTION FOR ACME FURNITURE











MODEL#02347

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

*** Do not fully tighten screws until fully assembled***

| COMPONENT PARTS | | |
|-----------------|---|----------|
| DESCRIPTION | PART NAME | QTY(PCS) |
| K | SIDE PANEL  | 4 |
| L | BASE  | 2 |
| M | CENTER WOOD SHELVES  | 2 |
| N | BACK CORNER POST  | 2 |
| O | SIDE POST  | 4 |
| P | FRONT POST  | 4 |
| Q | MIRROR  | 4 |
| R | FRONT GLASS  | 2 |
| S | DOOR GLASS  | 4 |
| T | GLASS SHELVES  | 4 |
| U | DOWEL  | 2 |

HARDWARE REQUIR

| | | | | |
|---|---|--------------------|------------------|--------|
| A |  | LONG MACHINE SCRES | Ø 11.5mm X 37mm | 20 PCS |
| B |  | WOOD SCREWS | Ø 7.9mm X 31.5mm | 56 PCS |
| C |  | HANGERS BLOTS | Ø 10mm*11mm | 20 PCS |
| D |  | SHELF SUPPORTS | | 20 PCS |
| E |  | MAGNETS | | 4 PCS |
| F |  | GLASS PAD | | 4 PCS |
| G |  | GLASS PROTECTOR | | 4 PCS |
| H |  | HINGE | | 8 PCS |
| I |  | HINGE SCREW | Ø 5mm | 16 PCS |
| J |  | HINGE SCREW CAP | Ø 9mm | 8 PCS |

Attention

***Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled.

Carefully check parts and packing materials prior to ordering replacement.

How to assemble:

STEP 1). INSERT HANGER BOLT (C) INTO POST(N.O.P.)


STEP 2). INSERT POST (N.O.P.) INTO BASE (L) BY USING LONG MACHINE SCREW(A)

STEP 3). SLIDE MIRROR(Q) INTO POST(N.O.)

STEP 4). SLIDE GLASS (R) INTO POST(P)

STEP 5). SAME AS STEP 01.

STEP 6). TO ATTACH CENTER WOOD SHELF (M) BY USING LONG MACHINE SCREW(A) TO ASSEMBLED FRAMES.



STEP 7). TO ATTACH HINGE(H) TO DOOR GLASS (S) BY USING HINGE SCREW (I) TO TIGHTEN, THEN PUT HINGE SCREW CAP (J) ON HINGE (H).


STEP 8). INSERT HINGE SCREW CAP (J) AND HINGE (H) INTO THE DRILLED HOLE ON CENTER WOOD SHELF AND SLIDE ASSEMBLED DOOR GLASS OF STEP (07) INTO HINGE (H), THEN TIGHTEN BY USING HINGE SCREW(I).


STEP 9). SAME AS STEP(01.)-(08.) AND UPSIDE DOWN AS UPPER CABINET AND USE DOWELS (U) TO FIRM IT.

STEP 10).TAKE OFF THE BACK STICKER OF GLASS PAD(F) AND INSERT INTO GLASS PROTECTOR(G).


STEP 11).SLIDE UPPER-RIGHT AND UPPER-LEFT CORNER OF EACH DOOR GLASS(S) INTO GLASS PROTECTOR(G) SEPERATELY.

STEP 12). INSERT WOOD SCREW (B) THROUGH MAGNET (E) AND TIGHTEN INTO UNDERSIDE TOP (L.M)





STEP 13).INSERT WOOD SCREW(B)
THROUGH SIDE PANEL (K) AND TIGHTEN.



STEP 14). INSERT SHELF SUPPORT (D) INTO POST (N.O.P.)
STEP 15). PUT GLASS SHELVES (T) ON SHELF SUPPORT(D)